


調子板
TENSION BRACKET



調子板
TENSION BRACKET

No	部品番号 PART NO	数量 QTY	品名	DESCRIPTION
1	C0079	1	調子板	TENSION BRACKET
2	19531	8	調子皿	TENSION DISC
3	19532	4	丸皿	TENSION RELEASE WASHER
4	19533	4	渦巻スプリング(1.4)	TENSION SPRING
5	28206	4	ローレットストッパー	NUT WASHER
6	19513	4	ローレットナット	NUT 1/4X40
7	C0080	1	糸調子棒	THREAD CONTROLLER STUD
8	C0081	1	糸引スプリング	THREAD CONTROLLER SPRING
9	10694	4	二重皿	THREAD CONTROLLER DISC
10	C0082	1	二重皿止めねじ	SCREW
11	19534	1	ローレットナット	NUT
12	10690	1	スプリング受	THREAD CONTROLLER SPRING STOP
13	10650	1	スプリング受止めねじ	SCREW 3.4X36 L=6.0
14	15517	1	大糸掛(左)	THREAD RETAINER (LEFT)
15	10545	1	大糸掛止めねじ	SCREW 11/64X32 L=9.0
16	11142	1	大糸掛止めねじワッシャー	WASHER
17	C0083	1	糸ゆるめ板	TENSION RELEASE PLATE
18	19422	2	糸ゆるめ板段ねじ	SCREW
19	10720	1	糸ゆるめピン	TENSION RELEASE PLATE ROD
20	C0085	1	糸ゆるめピンA	TENSION RELEASE PIN A
21	C0086	1	糸ゆるめピンB	TENSION RELEASE PIN B
22	C0087	1	糸ゆるめピンC	TENSION RELEASE PIN C
23	C0088	1	糸ゆるめピンD	TENSION RELEASE PIN D
24	C0089	1	ワッシャー	WASHER
25	C0090	1	ワッシャー	WASHER
26	C0079C	1	調子板(組)	TENSION BRACKET COMPLETE