

H-2BL-AE-1 PARTS LIST ERRATA / パーツリスト 訂正表

Thick character is a correction point.
太文字が訂正箇所です

Page	No.	PARTS No. 部品番号		品名	DESCRIPTION
		旧 / Old No.	新 / New No.		
3, 4	17	24514	24514	締めねじ	SET SCREW, SM9/64X40 L=7
	42	24051	24051	針棒案内締めねじ	SCREW, SM11/64X40 L=8
5, 6	5	24064	24064C	押え上げレバー (組)	LIFTER LEVER, P-BAR ASSY
	6	24065			
	7	24066			
5, 6	37-1	24083 ⇒	27083-02	押え足 (φ3)	PRESSER FOOT (d=3)
5, 6	37-2	24526 ⇒	24083	押え足 (φ2.5)	PRESSER FOOT (d=2.5)
7, 8	7-2	24548 ⇒	—	—	—
<div style="display: flex; align-items: center;"> <div style="border: 1px solid black; padding: 5px; margin-right: 20px;"> <p style="text-align: center;">" オプション部品 / OPTION PARTS "</p> <p style="text-align: center;">7-2</p> </div> <div style="font-size: 2em; margin-right: 20px;">⇒</div> <div style="border: 1px solid black; padding: 20px; text-align: center;"> <p>廃止</p> <p>DISCONTINUED</p> </div> </div>					
7, 8	23	24223 ⇒	24233	送り腕 (軸付き)	FEEDING ARM SHAFT ASSY
9, 10	5	24536	24536	送り歯締めねじ	SCREW, SM1/8X44 L=6.8
	7	24537	24537	締めねじ	SCREW, SM3/16X28 L=16
11, 12	51	24292	24292	連結押え	HOLDER
14, 15	31	24033 ⇒	24497	下軸メタル (右)	BUSH, R
	45	24079	24079	止めねじ	SET SCREW, SM11/64X 40 L=10
19, 20	23	08118C ⇒	25649C	ドライバー (4点組)	SCREW DRIVER COMPLETE
	24	—	40163	頭部受け棒	HEAD REST
	25	24807 ⇒	MH-001	検出器アダプター	SYNCHRONIZER ADAPTOR
	26	24808 ⇒	17529	検出器支え棒	SYNCHRONIZER SUPPORT
	27	37102 ⇒	37102	ナット	NUT, M6